

Make 2 Sets
Rear

spokes semi gloss black

70, 69, 68, 67, 66, 65, 64, 71, 72, 73, 74, 75, 76, 77

Make 2 Sets
Front

spokes semi gloss black

13

60, 61, 59, 62, 63

Glue, then paint aluminium

12

Make 2 Sets

temporary \varnothing 0.5 wire no glue!

50 titanium gold

Semi gloss black 51

52, 53, 54, 55, 56, 57, 58

Decal 5

gun metal 49

Polished 48

Make 2 Sets

11

Glue, then paint aluminium

keep slots clear for wing support

cut 2 wires \varnothing 0.5 x 2.5mm

42, 43, 44, 45, 46

BEND

2.50

5

Aluminium

Glue FIRST then, paint red

93, 94, 95, 96, 97, 98, 99, 100

101

BEND

half etch on underside

102

18

Polish end

89 Flat black

90

92 \varnothing 0.5 x 14.8mm cut wire

Polish end

Flat black 91

17

\varnothing 0.5mm wire x 29.4mm

Bend in template A

81, 82, 83, 84, 85, 86, 87, 88

Bend in template B

16

80, 78, 79

5

Polish

132 Straps Flat Black

133 Buckles Silver

134 Flat black

135 \varnothing 0.5 x 4.5

136, 137, 138, 139

140 Aluminium

141 \varnothing 0.5 x 7.5mm cut wire

142

125 Aluminium

126 gun metal

127, 128, 129 Semi gloss black

130 Aluminium

131 gun metal

143

23

117, 118 white, 119, 120 white, 121

22

Aluminium

Red 115, Red 114, Red 113

21

112 BEND

107 Red

109 Red

110 White

111

20

103, 104 Flat black

105, 106

11

3

Semi gloss black 159

160

157, 158, 159, 160

Polish 157

160

150 Semi gloss black

29

Semi gloss black 155

Semi gloss black 154

156

insert into slots from step 10

28

Bend wire \varnothing 0.7 x 12.9mm

152

153

Bend wire \varnothing 0.7 x 31mm

26

\varnothing 0.5 x 12.5mm cut wire

147 Polish

148, 149, 150, 151

25

143, 144 Polished

145, 146 Polished

3